

## § 250.700

## 30 CFR Ch. II (7–1–00 Edition)

(c) When the lubricator is initially installed on the well, it shall be successfully pressure tested to the expected shut-in surface pressure.

[53 FR 10690, Apr. 1, 1988. Redesignated and amended at 63 FR 29479, 29485, May 29, 1998]

### Subpart G—Abandonment of Wells

#### § 250.700 General requirements.

(a) The lessee shall abandon all wells in a manner to assure downhole isolation of hydrocarbon zones, protection of freshwater aquifers, clearance of sites so as to avoid conflict with other uses of the Outer Continental Shelf (OCS), and prevention of migration of formation fluids within the wellbore or to the seafloor. Any well which is no longer used or useful for lease operations shall be plugged and abandoned in accordance with the provisions of this subpart. However, no production well shall be abandoned until its lack of capacity for further profitable production of oil, gas, or sulphur has been demonstrated to the satisfaction of the District Supervisor. No well shall be plugged if the plugging operations would jeopardize safe and economic operations of nearby wells, unless the well poses a hazard to safety or the environment.

(b) Lessees must plug and abandon all well bores, remove all platforms or other facilities, and clear the ocean of all obstructions to other users. This obligation:

(1) Accrues to the lessee when the well is drilled, the platform or other facility is installed, or the obstruction is created; and

(2) Is the joint and several responsibility of all lessees and owners of operating rights under the lease at the time the obligation accrues, and of each future lessee or owner of operating rights, until the obligation is satisfied under the requirements of this part.

[53 FR 10690, Apr. 1, 1988, as amended at 62 FR 27955, May 22, 1997. Redesignated at 63 FR 29479, May 29, 1998]

#### § 250.701 Approvals.

The lessee shall not commence abandonment operations without prior approval of the District Supervisor. The

lessee shall submit a request on Form MMS-124, Sundry Notices and Reports on Wells, for approval to abandon a well and a subsequent report of abandonment within 30 days from completion of the work in accordance with the following:

(a) *Notice of Intent to Abandon Well.* A request for approval to abandon a well shall contain the reason for abandonment including supportive well logs and test data, a description and schematic of proposed work including depths, type, location, length of plugs, the plans for mudding, cementing, shooting, testing, casing removal, and other pertinent information.

(b) *Subsequent report of abandonment.* The subsequent report of abandonment shall include a description of the manner in which the abandonment or plugging work was accomplished, including the nature and quantities of materials used in the plugging, and all information listed in paragraph (a) of this section with a revised schematic. If an attempt was made to cut and pull any casing string, the subsequent report shall include a description of the methods used, size of casing removed, depth of the casing removal point, and the amount of the casing removed from the well.

[53 FR 10690, Apr. 1, 1988, as amended at 58 FR 49928, Sept. 24, 1993. Redesignated at 63 FR 29479, May 29, 1998]

#### § 250.702 Permanent abandonment.

(a) *Isolation of zones in open hole.* In uncased portions of wells, cement plugs shall be set to extend from a minimum of 100 feet below the bottom to 100 feet above the top of any oil, gas, or freshwater zones to isolate fluids in the strata in which they are found and to prevent them from escaping into other strata or to the seafloor. The placement of additional cement plugs to prevent the migration of formation fluids in the wellbore may be required by the District Supervisor.

(b) *Isolation of open hole.* Where there is an open hole below the casing, a cement plug shall be placed in the deepest casing by the displacement method and shall extend a minimum of 100 feet above and 100 feet below the casing shoe. In lieu of setting a cement plug